



Tactical Walls

Please visit us at tacticalwalls.com for more information

Concealment Cover Installation Instructions

Series 1450 Concealment Cover Instructions:

Step 1. Please be sure to confirm that your cover is going to fit where you would like to place it. Check outlet and switch placement, consider the distance to doorjamb and trim. Be sure to measure the TOTAL open distance of the mirrors and confirm that it will fit where you want to put it BEFORE you even cut a hole in your wall to install your insert. As always, wear your proper safety equipment, and measure twice cut once.

Step 2. Fully read the instructions to the complete installation and begin once you have confirmed all safety considerations, and clearance and fit possibilities.

Step 3. Follow insert installation instructions and do steps 1-7 ONLY.

Step 4. You are NOW ready to begin the install of your locking or non locking concealment cover. This may require the help of a friend. Lay the mirror large or small down on the floor and slide it open. The drawer slides will come completely off if you depress the small plastic tab and slide the two halves of the slide apart. With the two halves apart you can now mount the back half (the half that will stay stationary on the wall to the wall.)

Step 5. Hold the back frame of your mirror to the wall fitting the insert into the open hole area. This is where a friend will come in handy. While you are holding the frame in place against a wall, confirm that the frame is square and level. Locate the 4 mounting holes in the frame. They are 16" apart and should be centered on the two studs in your wall. While holding the frame in place install the 4 supplied screws into the studs. With the screws installed the frame is now self supporting. If you did not hit a stud you may need to adjust your mirror right or left as necessary. Be sure to anchor your mirror frame to the studs. The mirrors are heavy and if only screwed into drywall over time, they WILL fail, possibly causing damage and injury. So make sure the frame is screwed to the studs. Now follow remaining steps 8-11 on your insert installation instructions.

Step 6. With the back frame securely mounted to the wall, you are now ready to install the front concealment frame and slides. Please note. The slides on the rear frame have some adjustment in them. If you slide the front frame on and it is not sitting completely square on the rear frame you may need to adjust the slides on the rear frame. You can do this by slightly loosening the rear slide screws and adjusting the frame as necessary. In extreme cases if it is still not square you may even have to adjust the slide of the back of the concealment frame itself. Regardless, whichever slide you adjust, be certain to tighten all screws again before re-assembly. Now that everything is adjusted and square, slide the front concealment frame onto the slides and close your concealment cover.

Series 1410 Concealment Cover Instructions:

Step 1. Please be sure to confirm that your cover is going to fit where you would like to place it. Check outlet and switch placement, consider the distance to doorjamb and trim. Be sure to measure the TOTAL open distance of the mirrors and confirm that it will fit where you want to put it BEFORE you even cut a hole in your wall to install your insert. As always, wear your proper safety equipment, and measure twice cut once.

Step 2. Fully read the instructions to the complete installation and begin once you have confirmed all safety considerations, and clearance and fit possibilities.

Step 3. Follow insert install instructions and do steps 1-7 ONLY.

Step 4. You are NOW ready to begin the install of your locking or non locking concealment cover. This may require the help of a friend. With the cover open, you can now mount the back half (the half that will stay stationary on the wall to the wall.)

Step 5. Hold the back frame of your mirror to the wall fitting the insert into the open hole area. This is where a friend will come in handy. While you are holding the frame in place against a wall, confirm that the frame is square and level. Locate the 4 mounting holes in the frame. They are 16" apart and should be centered on the two studs in your wall. While holding the frame in place install the 4 supplied screws into the studs. With the screws installed the frame is now self supporting. If you did not hit a stud you may need to adjust your mirror right or left as necessary. Be sure to anchor your mirror frame to the studs. The mirrors are heavy and if only screwed into drywall over time, they WILL fail, possibly causing damage and injury. So make sure the frame is screwed to the studs. Now follow remaining steps 8-11 on your insert installation instructions.

Step 6. With the back frame securely mounted to the wall, you can close your concealment cover.

Congratulations, you have just successfully installed your concealment cover. We hope you enjoy years of use of your new concealment wall insert! Thank you for your purchase!