



1450 FRAMED HINGED CONCEALMENT MIRROR INSTALLATION

Read Carefully Before Installation

The Tactical Walls Framed Hinged Concealment Mirrors are designed for a standard 2x4 construction framed 16" on center studs. It is crucial that the mirror is fastened to studs to avoid it pulling off the wall. A professional is recommended but not required for a safe and accurate installation.

IS YOUR WALL CLEAR FOR INSTALLATION?

Before installing your concealment mirror on your wall, make sure you know what is behind the wall, that is plumbing, electrics, ducts etc. **AN IMPROPERLY INSTALLED MIRROR MAY CAUSE BODILY HARM, DAMAGE TO USER EQUIPMENT, AND CREATE A HOUSE HAZARD.**

GOT TOOLS?

Studfinder, tape measure, level, pencil/marker, hole saw, jigsaw/sawzall/circular saw, drill/driver, inspection mirror and flashlight/worklight.

WE RECOMMEND!

A second pair of hands and eyeballs will significantly ease this installation process, especially for larger mirrors.

FINALLY, READ AND STUDY ALL INSTRUCTION STEPS BEFORE CUTTING OR FASTENING!

Have questions? Contact us via provided support email below or visit our website for installation video tutorials. Of course, don't forget to like and follow Tactical Walls and share your setup with us and the world!



Share your setup with us and the world!



support@tacticalwalls.com
TACTICALWALLS.COM

INSTALLATION PROCESS FOR FRAMED HINGED CONCEALMENT MIRRORS

1

Release the hinged door from subframe by placing magnetic key on magnetic lock region (you will feel a tug). If nothing happens, flip the magnetic key.

2

Using a level, locate & mark wall studs 16" apart & cut a rectangular opening between the studs in wall to match dimensions of mirror subframe opening. Mock it up & mark opening on wall if needed.

